



Box contents

- the stroller frame
- 2 front wheels
- 2 rear wheels



1. Unfolding

- Undo the clasp on the side.
- Lift the stroller by the push bar to unfold the stroller.
- Step with your foot on the rear axle while lifting up the push bar to make sure the stroller is fully unfolded. Do not forget this step, as the stroller needs to be unfolded completely.



2. Front wheels

- Attache the front wheels by pushing the pins into the frame of the stroller.
- Remove the front wheel by pushing in the small metal tab that is on the frame near the wheel. Repeat on the other side. (If it is difficult to push the metal tab, use an object like a pen)



3. Rear wheels

- Push the rear wheels onto the frame.
- make sure the brakes point backwards and the pins fall into place.
- To remove the rear wheels, press the metal tab near the wheel and pull it off of the frame.



4. Folding

- Make sure the front wheels are not locked.
- Press the small button on the pushbar with one finger and then press the large button with your hand.
- Fold the pushbar down and then push the cabin forward and fold it.



- Under the cabin is a handle, pull it to collapse the frame of the stroller.
- Fasten the clasp on the side of the stroller to prevent it from unfolding during transport.

Tip 1

Really make sure the stroller frame is unfolded completely. The supports should be fully extended.



Tip 2

The front wheels can rotate 360°. To prevent the wheels from turning, lock it by pushing the switch above the wheel down on each side.



Caution

- This carrier is for pets only.
- Max. capacity 11kg.
- Use the fastening lines at all times.
- Fully unzip the cabin before folding.
- Do not use when nuts or screws are loosening.
- Clean fabric with mild household soap and water.
- If wheel squeaks or rotates with difficulty, apply grease (like vaseline).
- Read warranty terms on innopet.nl



InnoPet City Buggy Instruction manual

Contact customer service:
+31 (0) 85 079 60 12
support@innopet.nl
<https://innopet.nl/en/contact>



Scan the QR code for
detailed video instructions
for your InnoPet stroller or
visit innopet.nl

